


**YAESU**  
The radio

# **SCU-17** USB INTERFACE UNIT

## Instruction Manual





## Introduction

The SCU-17 interface unit may be used for CAT control of the transceiver with a computer via a USB connection; and for communications using SSTV, RTTY and PSK digital modes.

**Note:** YAESU does not produce CAT, SSTV, RTTY and PSK System operating software, due to the wide variety of personal computers, operating systems, and applications in use today.

- The SCU-17 provides CAT communication through the USB terminal when a PC does not have an RS-232C connection.
- The SCU-17 is equipped with a USB audio system device, so the TX and RX audio system signals are accessible to the SCU-17 through the USB cable. Therefore, the supplied USB cable is the only connection needed between the SCU-17 and PC.
- The SCU-17 is equipped with a two-channel USB serial device and enables the various transmission modes and the CAT communication simultaneously.
- The SCU-17 operates from the USB bus power; you do not need to prepare an external power supply.
- For RF isolation, the SCU-17 is designed with photo relays for the PTT/FSK terminals. AF transformers are used in the AUDIO IN/OUT lines to provide excellent ground isolation.
- The SCU-17 is equipped with the TX and RX audio controls on the front panel, for convenient level adjustment.
- LED indicators on the SCU-17 front panel monitor the PTT and FSK control. The operating conditions may be quickly confirmed.
- When using the SCU-17 to perform TX control, the transceiver may switch to transmit mode when the computer is started.

### Safety Precautions (Be Sure to Read)

Be sure to read the safety precautions of Operating Manual of the compatible transceiver to use this product safely.

# **Virtual COM port driver Installation**

---

Install the virtual COM port driver on the personal computer before using the SCU-17 USB interface unit.


Please see the USB Driver (Virtual COM Port Driver) on the Yaesu Website for details refer to (<http://www.yaesu.com/>) in the FTDX1200 product files section.

**Note:** Do not connect the USB cable and SCU-17 to your personal computer until after the “virtual COM port driver” installation is completed, because an incorrect driver may be installed.



- For assistance with the software port configuration, refer to “How to Confirm the Installation, and the COM Port Number” in the “Virtual COM port Driver Installation Manual”.
- For information on port configuration for commercial and free computer software, refer to the manual for the software being used.
- When using the USB cable to supply TX and RX audio signals, set the Sound Card (input and output) settings to “USB Audio CODEC”.
- When using the USB cable for computer TX control, the transceiver may switch to transmit mode when the computer is started, etc.
- YAESU does not provide technical support for the use or operation of commercial or free computer software.

# Accessories

USB cable (Type "A" male to Type "B" male) ..... 1 pc




RS-232C cable (female to female, Straight Type) ..... 1 pc




- |   |            |   |     |
|---|------------|---|-----|
| ① | N/A        | ⑥ | N/A |
| ② | SERIAL IN  | ⑦ | RTS |
| ③ | SERIAL OUT | ⑧ | CTS |
| ④ | N/A        | ⑨ | NC  |
| ⑤ | GND        |   |     |

Connection cable (MDIN6P - MDIN6P) ..... 1 pc




- |   |          |   |         |
|---|----------|---|---------|
| ① | DATA OUT | ④ | FSK OUT |
| ② | GND      | ⑤ | DATA IN |
| ③ | DATA PTT | ⑥ | SQL IN  |

3.5 mm Stereo plug ..... 2 pcs



PTT/FSK




AUDIO


Instruction manual

# Controls & Connections

## Front Panel



## Rear Panel



### ① RX audio level control knob

This knob adjusts the RX audio level.

### ② TX audio level control knob

This knob adjusts the TX audio level.

### ③ FSK Indicator

This indicator illuminates when the Mark frequency is shifted.

### ④ TX Indicator

This indicator illuminates during transmission.

### ⑤ POWER Indicator

### ⑥ USB Connector

Connect to a computer from this jack using the supplied USB cable.

### ⑦ CAT/RS-232C Jack

This 9-pin serial DB-9 jack allows CAT communication of the transceiver.

Connect a supplied RS-232C cable here and to the transceiver.

### ⑧ 3.5 mm stereo Jack (PTT/FSK)

This 3-conductor, 3.5 mm stereo jack is used for PTT/FSK. For RF isolation, these terminals are designed with photo relays.

### ⑨ DATA Jack

This 6-pin (MDIN6P) jack allows DATA communication of the transceiver.

### ⑩ 3.5 mm stereo Jack (Audio IN/OUT)


This 3-conductor, 3.5 mm stereo jack is used for Audio IN/OUT. For RF isolation, AF transformers are used in the AUDIO IN/OUT lines.

This Jack is equipped with an attenuator that is applied to the audio output.


See page 15 for details about attenuation.

# System Setup

## FTdx1200




## FT-950




# System Setup

## FT-2000 Series / SCU-21




## FT-2000 Series / CT-39/A



SCU-17 DATA Jack Pin #	CT-39	CT-39A
#1	Black	Brown
#2	Brown	Red
#3	Red	Orange
#4	Orange*	Yellow
#5	Yellow	Green
#6	Green	Blue
Shell	Shield (BLK)	


\* : The CT-39 orange wire may be white




(as viewed from rear panel)

# System Setup

## FTdx9000 Series / SCU-22




## FTdx9000 Series / CT-39/A



SCU-17 DATA Jack Pin #	CT-39	CT-39A
#1	Black	Brown
#2	Brown	Red
#3	Red	Orange
#4	Orange*	Yellow
#5	Yellow	Green
#6	Green	Blue
Shell	Shield (BLK)	


\* : The CT-39 orange wire may be white




(as viewed from rear panel)

# System Setup

## FTdx5000 Series / SCU-21




## FTdx5000 Series / CT-39/A



SCU-17 DATA Jack Pin #	CT-39	CT-39A
#1	Black	Brown
#2	Brown	Red
#3	Red	Orange
#4	Orange*	Yellow
#5	Yellow	Green
#6	Green	Blue
Shell	Shield (BLK)	


\* : The CT-39 orange wire may be white




(as viewed from rear panel)

# System Setup


## FT-450D



## FT-817ND




## FT-857D




# System Setup

## FT-897D



## Interfacing to other transceivers



# PTT/FSK control and Attenuator Setting

The PTT/FSK setting may be changed and the audio output attenuator may be enabled by changing the configuration of an internal switch and a jumper.

1. Disconnect all the cables from the SCU-17.
2. Referring to Figure 1, remove the 4 screws attaching the top case, then remove the top case.
3. Refer to Figure 2 for the location of switch (S1001) and jumper (J1006).
4. Set the switch (S1001) and jumper (J1006).

S1001: PTT/FSK control setting

J1006: Attenuator setting to the audio output of the Audio IN/OUT jack.

5. Replace the top case, using the 4 screws removed in step (2) above.
6. Reconnect the cables to the SCU-17.




Figure 1




Figure 2

# Specifications

---

<b>Supply Voltage:</b>	DC 5.0 V ±5%, Negative Ground
<b>Current Consumption:</b>	130 mA
<b>Data Jack:</b>	PTT: Maximum output +25 V, 50 mA (open collector) FSK: Maximum output +25 V, 50 mA (open collector) DATA-IN: 100 mVrms @ 10 k Ohms DATA-OUT: 100 mVrms @ 600 Ohms
<b>FSK/PTT Jack:</b>	PTT: Maximum output +30 V, 250 mA (open drain) FSK: Maximum output +30 V, 250 mA (open drain)
<b>AUDIO Jack:</b>	AUDIO-IN: 100 mVrms @ 600 Ohms AUDIO-OUT: 100 mVrms @ 600 Ohms
<b>CAT/RS-232C Jack:</b>	RS-232C voltage level
<b>USB Connector:</b>	USB 1.1 or USB 2.0, USB bus power
<b>Case Size:</b>	4.37" (W) x 1.0" (H) x 2.91" (D) (111 x 25.4 x 74.0 mm)
<b>Weight (approx.):</b>	8.1 oz (230 g)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions; (1) this device may not cause harmful interference, and (2) this device must accept any interference including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Disposal of Electrical and Electronic Equipment

Products with the symbol (crossed-out wheeled bin) cannot be disposed of as household waste. Electronic and Electrical Equipment should be recycled at a facility capable of handling these items and their waste by products.



Please contact a local equipment supplier representative or service center for information about the waste collection system in your country.

# 特徴 / 準備

## 特徴

SCU-17 は、無線機の CAT 通信、SSTV、RTTY、PSK などの各種送信制御を USB ケーブルで接続したパソコンで行うことができるインターフェースユニットです。

- RS-232C の端子がないパソコンでも USB 端子を用いて CAT 通信を行うことができます。
- USB オーディオデバイスを搭載し、送信および受信オーディオ信号は USB ケーブルにて通信されますので、SCU-17 とパソコンの接続は、付属の USB ケーブルだけで接続可能です。
- 2 チャンネルの USB シリアルデバイスを搭載している為、CAT 通信と同時に各種の送信制御を行なうことが可能です。
- USB バスパワーにて動作しますので、外部電源は不要です。
- RF インターフェア対策の為、フォトリレーを使用した PTT/FSK 端子および、オーディオラインにトランスを使用し、GND アイソレーションされている AUDIO IN/OUT 端子を備えています。
- 送信および受信オーディオレベルの調整用ボリュームをフロントパネルに配置しましたので、各レベル調整を容易に行なうことができます。
- PTT および、FSK コントロールのモニター用 LED インジケータをフロントパネルに配置しましたので、一目で動作状態を確認することができます。

## 準備


SCU-17 を使用するには、使用するパソコンに、あらかじめ仮想 COM ポートドライバーをインストールする必要があります。

SCU-17 に仮想 COM ポートドライバーは付属していませんので、当社ホームページ ([http://www.yaesu.com/jp/amateur\\_index/driver/GetStart.html](http://www.yaesu.com/jp/amateur_index/driver/GetStart.html)) の「SCU-17 USB インターフェースユニット 仮想 COM ポートドライバー」掲載ページよりダウンロードしてください。



### 【ご注意】

- ・ 仮想 COM ポートドライバーのインストールが完了するまでは、SCU-17 とパソコンとを USB ケーブルで接続しないで下さい。仮想 COM ポートドライバーをインストールしないで SCU-17 とパソコンとを接続した場合、誤ったドライバーがインストールされて正しく動作しなくなる恐れがあります。
- ・ 無線機の電源が入っている状態でパソコンを起動すると、無線機が一瞬、送信状態になることがあります。このような場合には、パソコンを起動してから無線機の電源を入れてください。また、ご使用のソフトと無線機の送信制御を“RTS”で行なうように設定することで改善する場合があります。
- ・ SCU-17 を使用して無線機の通信制御を行うためのソフトのサポートは行っていません。
- ・ ご使用の無線機に付属装置（本機）を接続して、SSTV、RTTY、PSK などのモードを運用する時は、変更申請（届出）が必要になる場合があります。  
また、技術基準適合証明設備でない設備の変更申請には、JARD またはティエスエス（TSS）株式会社による保証認定が必要になります。

- USB ケーブル (A-B タイプ) ..... 1




- RS-232C ケーブル (メス - メス、ストレートタイプ) ..... 1




①	N/A	⑥	N/A
②	SERIAL IN	⑦	RTS
③	SERIAL OUT	⑧	CTS
④	N/A	⑨	NC
⑤	GND		

- コネクションケーブル (Mini-Din 6pin — Mini-Din 6pin) ..... 1




①	DATA OUT	④	FSK OUT
②	GND	⑤	DATA IN
③	DATA PTT	⑥	SQL IN

- 3.5 φ ステレオプラグ ..... 2



PTT/FSK




AUDIO


- 取扱説明書

# 各部の説明

## フロントパネル



## リアパネル



### ① 受信レベル調整ツマミ

受信オーディオレベルの調整を行うツマミです。

### ② 送信レベル調整ツマミ

送信オーディオレベルの調整を行うツマミです。

### ③ FSK インジケータ

マーク周波数が、あらかじめ設定してある周波数分シフトした際に点灯するインジケータです。

### ④ TX インジケータ

送信時に赤く点灯するインジケータです。

### ⑤ POWER インジケータ

### ⑥ USB 端子

付属のUSBケーブルを使用して、パソコンのUSB端子と接続します。

### ⑦ CAT/RS-232C 端子

付属のRS-232Cケーブルを使用して、無線機のCAT/RS-232C端子と接続します。

### ⑧ 3.5-mm ステレオジャック (PTT/FSK)

RFインターフェアを防ぐために、フォトリレーを使用したPTT/FSK端子です。

### ⑨ DATA ジャック


付属のコネクションケーブルを使用して、無線機のDATA端子やPACKET端子と接続します。

### ⑩ 3.5-mm ステレオジャック (AUDIO IN/OUT)


RFインターフェアを防ぐために、オーディオラインにトランスを使用し、GNDアイソレーション可能なAUDIO IN/OUT端子です。

なお、OUT端子(送信オーディオ出力)は、SCU-17内部のジャンパー設定を変更することにより、アッテネーターを動作させることができます(31ページ参照)。

## FTdx1200 との接続例




## FT-950 との接続例





# 無線機との接続

## FT-2000 シリーズとの接続例（オプションの SCU-21 を使用する場合）




## FT-2000 シリーズとの接続例（オプションの CT-39A を使用する場合）



# 無線機との接続

## FTDX9000 シリーズとの接続例（オプションの SCU-22 を使用する場合）



### □ RTTY で運用する場合

無線機の [RTTY] キーを押して運用モードを RTTY にします (FSK による RTTY 通信が可能です)。ご使用のソフトウェアの PTT 制御を “RTS”、FSK 制御を “DTR” で行う設定にします。


### □ PSK で運用する場合

- ・PKT モードを使用する  
無線機の [PKT] キーを押して運用モードを PKT にします。  
ご使用のソフトウェアの PTT 制御を “RTS” で行う設定にします。
- ・SSB モードを使用する  
ご使用のソフトウェアの PTT 制御を “DTR” で行う設定にします。

### □ SSTV で運用する場合


- ・PKT モードを使用する  
無線機の [WIDTH] ツマミをまわして WIDTH を 2400Hz に広げます。  
ご使用のソフトウェアの PTT 制御の設定を “RTS” にセットします。
- ・SSB モードを使用する  
ご使用のソフトウェアの PTT 制御の設定を “DTR” にセットします。

## FTdx9000 シリーズとの接続例（オプションの CT-39A を使用する場合）





# 無線機との接続

## FTdx5000 シリーズとの接続例（オプションの SCU-21 を使用する場合）




## FTdx5000 シリーズとの接続例（オプションの CT-39A を使用する場合）




# 無線機との接続


## FT-450D との接続例



## FT-817ND との接続例




## FT-857D との接続例




# 無線機との接続

## FT-897D との接続例



## その他の無線機との接続例

付属の 3.5 φステレオプラグを使用して、下図を参考に接続してください。



SCU-17 は、内部のジャンパー設定を変更することにより、AUDIO IN/OUT 端子の送信オーディオ出力側にアッテネーターを動作させることができます。また、内部のスイッチを切り換えることにより、PTT/FSK の制御 (PTT 制御 : RTS、FSK 制御 : DTR) を変更 (PTT 制御 : DTR、FSK 制御 : RTS) することができます。

1. SCU-17 に接続されている全てのケーブル類を外します。
2. 図 1 を参考に、4 本のネジを外して上ケースを外します。  
ケースが外れにくい場合は、下側のネジを緩めてください。
3. 図 2 を参考に、ジャンパー (J1006) の設定または、スイッチ (S1001) の切り換えを行います。
4. 上記 2 で外したネジ 4 本で、上ケースを取り付けます。
5. 上記 1 で外したケーブル類を接続します。




図 1




図 2

# 定格

電源電圧 : DC 5.0V ± 5%、(マイナス接地)  
消費電流 : 約 130mA  
入出力レベル : DATA ジャック  
PTT 出力端子 : 最大 +25V, 50mA (オープンコレクタ制御)  
FSK 出力端子 : 最大 +25V, 50mA (オープンコレクタ制御)  
DATA-IN : 100mVrms @ 10k Ω  
DATA-OUT : 100mVrms @600 Ω  
FSK/PTT ジャック  
PTT 出力端子 : 最大 +30V, 250mA (オープンドレイン制御)  
FSK 出力端子 : 最大 +30V, 250mA (オープンドレイン制御)  
AUDIO ジャック  
DATA-IN 端子 : 100mVrms @600 Ω  
DATA-OUT 端子 : 100mVrms @600 Ω  
CAT/RS-232C ジャック  
RS-232C レベル  
USB ジャック  
USB 1.1 または USB 2.0 (バスパワー電源供給)  
寸法 : 111(幅) × 25.4(高さ) × 74(奥行き) mm  
重量 : 約 230 g

本製品または他の当社製品についてのお問い合わせは、お買い上げいただきました販売店または、当社カスタマーサポートにお願いいたします。

八重洲無線株式会社 カスタマーサポート

電話番号 0120-456-220

受付時間 平日 9:00 ~ 12:00、13:00 ~ 18:00





Copyright 2018  
YAESU MUSEN CO., LTD.  
All rights reserved.

No portion of this manual may be  
reproduced without the permission of  
YAESU MUSEN CO., LTD.

**YAESU MUSEN CO., LTD.**

Tennōzu Parkside Building  
2-5-8 Higashi-Shinagawa, Shinagawa-ku, Tokyo  
140-0002 Japan

**YAESU USA**  
6125 Phyllis Drive, Cypress, CA 90630, U.S.A.

**YAESU UK**  
Unit 12, Sun Valley Business Park, Winnall Close  
Winchester, Hampshire, SO23 0LB, U.K.

1801R-ES  
Printed in Japan

